

NC - Normally Close  
NO - Normally Open

SIGNAL	INPUTS	LOCATION	TYPE	FUNCTION
Digital	PULSE_A	Local:2:I.Data[1].1	NO	When material A is ready, sensor HIGH, could be a proximity sensor inside Silo
Digital	PULSE_B	Local:2:I.Data[1].2	NO	When material B is ready, sensor HIGH, could be a proximity sensor inside Silo
Digital	TEMP	Local:2:I.Data[1].3	NO	A set temperature sensor which is HIGH if temperature within +/-5 of 100 degree C
Digital	PULSE_OUT	Local:2:I.Data[1].7	NO	Sensor become HIGH when dump process complete, we can use a proximity sensor
Digital	READY	Local:2:I.Data[1].5	NO	Sensor become HIGH when QA Tank is in position, we can use a proximity sensor
Digital	EMERGENCY	Local:2:I.Data[1].6	NC	emergency push button to stop all activities

SIGNAL	OUTPUTS	LOCATION	FUNCTION
Digital	VALVE_A	Local:2:O.Data[0].1	It opens and release ingredient A to mixer
Digital	VALVE_B	Local:2:O.Data[0].2	It opens and release ingredient B to mixer
Digital	AGIT_ON_LS	Local:2:O.Data[0].3	Agitator for low speed 200 rpm
Digital	AGIT_ON_HS	Local:2:O.Data[0].4	Agitator for high speed 500 rpm
Digital	HEATER	Local:2:O.Data[0].5	Heater to control temperature
Digital	VALVE_OUT	Local:2:O.Data[0].6	It opens to release material to the tank
Digital	QA_OUT	Local:2:O.Data[0].8	QA goes away process
Digital	QC_SAMPLE	Local:2:O.Data[0].9	sample process executed after 12 samples
Digital	GL1	Local:2:O.Data[0].10	Green LED turns ON when READY signal is HIGH
Digital	YL2	Local:2:O.Data[0].11	Yellow LED turns ON when any agitator is running
Digital	BL4	Local:2:O.Data[0].12	Blue LED turns ON when QC sample process running
Digital	RL3	Local:2:O.Data[0].13	RED LED light is ON when HEATER is running

SIGNAL	INTERNAL	LOCATION	FUNCTION
DIGITAL	RELAY	Local:2:O.Data[0].7	It is a latching output to automate the heater with TEMP sensor during process
TIMERS		PRE SET TIME	CONTROL
	T1	10000 ms (10 sec)	Ingredients A, B amount with T1.DN, T1.EN
	T2	20000 ms (20 sec)	Agitator High Speed timing with T2.DN, T2.EN
	T3	30000 ms ( 30 sec)	Agitator Low Speed timing with T3.DN, T3.EN
	T4	40000 ms ( 40 sec)	After heating Agitator Low Speed with T4.DN, T4.EN
	T5	15000 ms ( 15 sec)	Valve out with T5.DN, T5.EN
	T6	20000 ms (20 sec)	QA Out process with T6.DN, T6.EN
	T7	20000 ms (20 sec)	QC sample process with T7.DN, T7.EN

COUNTER	Setting	Control
C1	PRE- 13, ACC-1	It counts up the batches and then resets at 13th one

ASSUMPTIONS			
	1) Ready Signal is turned OFF when the agitating process starts		
	2) LS Agitating used for 40 seconds after heating		
	3) Valve A & B open at same time for 10 seconds after both pulse A & B are high		



